




How to add a user who only does Real-Time Monitoring

In some applications, an entrance guard may need a user account with permission to only perform real-time monitoring. A user with a specific role can be created to achieve this.


Create a **role** that only does Real-Time Monitoring

You can set many roles to manage the software and they can have different privileges. We have to create a role that can only do real-time monitoring.

Click [Add] on the [System—role] interface. Choose the Real-Time Monitoring segment. Click [OK].



Then a role that can only do real-time monitoring is created.



Add a **user** with a special role

Click [Add] on the [System—User] interface.

Set the user name to “**Bill**”, and the default password is “111111”. The password can be changed



ZK Access Quick Start Guide

to a specific one.

Make sure the user is not a super user, and choose the “only monitor” role for the user.

The screenshot shows the 'User Management' interface in ZKAccess5.0. The 'Add User' form includes fields for Username (Bill), Password, Confirm Password, Authorize Department, Authorize Area, First name, Last name, E-mail address, Staff status, and Superuser status. The 'Role' dropdown menu is set to 'only_monitor' and is highlighted with a red box. The interface also includes a 'Fingerprint Registration' section and buttons for 'Save and New', 'OK', and 'Cancel'.

New User LOGIN

When **Bill** is a user who only does Real-Time Monitoring logs in to the software:



The interface for **Bill** is as follows: he can only access the Real-Time Monitoring interface.

